




Key to Wiring Diagram

Type 2

(from August 1962) Chassis No. 971 550

A - Battery	M ¹ - Parking light, left
B - Starter	M ² - Parking light, right
C - Generator	N - Distributor
D - Starter/ignition switch	O - Coil
E - Windshield wiper switch	O ¹ - Automatic choke
E ¹ - Switch for fan motors	P ¹ - Spark plug connector for cylinder No. 1
F - Lighting switch	P ² - Spark plug connector for cylinder No. 2
G - Turn indicator switch	P ³ - Spark plug connector for cylinder No. 3
H ¹ - Horn button	P ⁴ - Spark plug connector for cylinder No. 4
H ² - Horn	Q ¹ - Spark plug for cylinder No. 1
H ³ - Buzzer	Q ² - Spark plug for cylinder No. 2
H ⁴ - Buzzer button	Q ³ - Spark plug for cylinder No. 3
J ¹ - Dimmer switch	Q ⁴ - Spark plug for cylinder No. 4
J ² - Flasher relay	R - Radio
J ³ - Stop light switch	R ¹ - Aerial
J ⁴ - Oil pressure switch	R ² - Connector for rear loudspeaker (Only Models 241—244 and 251)
J ⁵ - Switch for interior light	S - Fuse box
J ⁶ - Fuel gauge sender unit	S ¹ - Connector with fuse
J ⁷ - Socket	T - Cable connector
J ⁸ - Switch for Red Cross Lamp	U ¹ - Turn indicator light, front left
J ⁹ - Speedometer cable switch	U ² - Turn indicator light, front right
K ¹ - High beam warning light	W - Windshield wiper motor
K ² - Generator and cooling warning light	W ¹ - Fan motors
K ³ - Turn indicator warning light	X ¹ - Stop/tail/indicator light, rear left
K ⁴ - Oil pressure warning light	X ² - Stop/tail/indicator light, rear right
K ⁵ - Speedometer light	Y ¹ - Front interior light
K ⁶ - Fuel gauge light	Y ² - Ambulance compartment light
K ⁷ - Clock light	Y ³ - Rear interior light
K ⁸ - Ventilator fan warning light	Z - License plate light
L ¹ - Twin-filament bulb, left	① - Ground strap from battery to body
L ² - Twin-filament bulb, right	② - Ground strap from transmission to body
L ³ - Spot-light bulb	③ - Windshield wiper motor ground cable
L ⁴ - Red Cross light bulb	④ - Fan motor ground cable
L ⁵ - Reversing lamp bulb	

Black dotted lines = Service installation

Grey data = For Ambulance only




Wiring Diagram and Fuses

Type 2

(from August 1962) Chassis No. 971 550

Fuses



Fuse box below parcel shelf

Grey data = For Ambulance only